



# TorqueAQ

Water based table tennis glue

## Killerspin TorqueAQ Application Instructions

[www.megaspin.net/store](http://www.megaspin.net/store)



1 Attach the foam applicator to the supplied plastic clip.



2 Apply a quarter size amount of TorqueAQ on each of the rubber sheets.



3 Spread the glue evenly.



4 Example of properly spread glue.



5 Apply a small amount of TorqueAQ to one side of the blade, and spread evenly. Since the foam roll absorbs the glue, less glue is needed. After use, dispose the foam roll.



6 Let the rubber and blade dry for about 8-10 minutes or until the glue turns transparent. Lay the rubber on the blade and smooth it out. For faster drying time, a hair dryer may be used, but only at the lowest temperature setting for optimum results.



7 When the rubber sticks firmly, trim the excess rubber from the blade using a sharp pair of scissors. Repeat procedure to apply the rubber to the remaining side of the blade.



8 Place a heavy object on the assembled racket or place the racket in a Killerspin Racket Jacket overnight for the best adhesion.



9 Your racket is ready for competition play!!